


STRETCHER

Front Panel



Rear Panel



The rear panel is made up of 3 specific areas:

- The LED Panel - Used to identify various operations of the STRETCHER
- The Adjustment Buttons - Used to make adjustment operations (Select, -, +, and Save)
- The Output Sockets - Used to connect the STRETCHER to the four display monitors.

Installation Instructions

- Ensure the power supply for the PC is disconnected.
- Connect the DVI output from the PC to the Input 1 socket on the front panel
- Connect the four displays to the output sockets on the rear panel.
- Connect the power cord and switch on the power supply.
- Power up the PC

The Power LED located on the rear panel will illuminate to indicate that power has successfully been applied to the unit.

When power is introduced to the STRETCHER the unit will carry out a self test, if the Ready LED on the rear panel illuminates then the self test is successful and the STRETCHER is functioning correctly.